

PCR43302RE, PCR43302R

2-Channel, 433MHz Penta Receiver with Relay outputs

Features

- Frequency hopping between 433.10 to 434.70MHz
- Coding using 12-way dipswitch or encrypted codes
- Momentary and latching modes are user selectable
- Antenna diversity for robust link with extended range
- Unlimited remotes can be programmed to the receiver
- Compatible with PentaFOB® and PentaCODE® remotes
- Wide operating supply voltage and low current consumption
- Add, edit and delete individual PentaFOB remotes with programmer
- On-board diagnostic LED's to indicate correct power, reception and relay activation



Applications

- Keyless access control for automatic gates and doors
 - Home automation i.e. garden lights, swimming pool control etc.
 - Security, lighting and automotive controls
- and anywhere else you need a wireless signal to transmit a contact closure

Description

PCR43302RE - Comes enclosed in a case

PCR43302R - PCB only. Easily integrates into custom cases

This receiver is compatible with “PentaFOB®” and “PentaCODE®” remotes. The receiver can be easily installed into your existing automatic gate opener or garage door controls. Other applications include light control, security shutters or anywhere else you need a wireless signal to transmit a contact closure.

The PentaCODE® dual coding system gives the installer the option to use the classic 12-way dip switch coding or one of over 17 billion encrypted codes.

With the 12-way dip switch, just match the keyring remotes and the receiver's dip switch and it's coded. With the encrypted code, you switch all the 12-way dip switches OFF and the remote and receiver automatically goes into the encrypted coding. Please see coding instructions for encrypted coding procedure.



PCR43302R (No Case Version)

Output Modes

Relay output on the receiver can be set to function in different modes. By default, the mode is momentary. Each channel is controlled independently except in “***Roller Shutter Mode***”.

3- way Dipswitch setting Ch1/Ch2	Modes
	<p>“Momentary” Relay stays “ON” for as long as the transmitter button is pressed. “<i>Press and hold</i>”</p>
	<p>“Latching” Relay remains “ON” until next press of the transmitter button. <i>Similar to switching “on” and “off” a light.</i></p>
	<p>“Delayed Off ” Relay stays “ON” for 1-300 seconds, adjustable by trimpot.</p>
	<p>“On-Off” This mode requires a 2-channel or a 4-channel remote. Receiver Relay 1: Channel 1 will always switch the relay “ON” Channel 2 will always switch the relay “OFF” Receiver Relay 2: Channel 3 will always switch the relay “ON” Channel 4 will always switch the relay “OFF” Receiver relay 2 will only work in “ON-OFF” mode with PentaCODE® remotes</p>
	<p>“Roller Shutter Mode” Open/stop/close cycle This mode requires a single button on remote* To use this mode, both Ch-1 and Ch-2 mode selection dipswitches must be set the same. Relay 1 and relay 2 are interlocked. Trimpot adjusts relay “ON” time from 30-120 sec. 1st Press : Relay 1 is “ON” 2nd Press : Relay 1 is “OFF” 3rd Press : Relay 2 is “ON” 4th Press : Relay 2 is “OFF”</p>
	<p>“Instant OFF ” Same is “Delayed Off ” except relay will switch “OFF” as soon as the PCK43304W input is deactivated</p>
	<p>“Security latching ” Relay will switch “ON” and stay “ON” until supply to receiver is momentarily interrupted.</p>

Customised Software

Custom output modes can be programmed to do special functions. Call Elsema for more details.


Products in the Range

			
PCR43301RE 1-Channel Receiver with Relay Output. Enclosed in a case	PCR43302P 2-Channel Plug in type Receiver with Open Collector Output	PCR43302R 2-Channel Receiver with Relay Outputs	PCR43302RE 2-Channel Receiver with Relay Outputs. Enclosed in a case
			
PCR43301240R 1-Channel Receiver with 240VAC mains supply	PCR43301240RE 1-Channel Receiver enclosed in an IP66 case	PCR43302240R 2-Channel Receiver with 240VAC mains supply	PCR43302240RE 2-Channel Receiver enclosed in an IP66 case
			
PCR43304R 4-Channel Receiver with Relay Outputs	PCR43304RE 4-Channel Receiver enclosed in an IP66 case	PCR43305R 5-Channel Receiver with Relay Outputs	PCR43305RE 5-Channel Receiver enclosed in an IP66 case

Technical Data

Supply Voltage	12 to 24 Volts AC or DC	
Standby Current	21mA standby at 24VDC	
Frequency Band	433.100 to 434.700MHz	
Receiver Sensitivity	0.316uV (-117dBm)	
Operating Temperature Range	-5 to 50°C	
Receiver Memory Storage	Unlimited Remotes	
Decoding System	Encrypted 17 billion codes combinations or On board 12-way code switch	
Outputs	Two change over relay outputs, rated at 10 Amps 240VAC.	
Relay Contacts	Common (C), Normally Closed (NC) & Normally Open (NO)	
Connections	Supply & output: 8-way female connector	
Antenna 1	ANT433 series for long range applications. Antenna wire for short range applications	
Antenna 2	Use second antenna for extended range	
Operating Range	Refer to the remote control or transmitter datasheet	
Dimensions	PCR43302R: 87 x 52 x 20mm	PCR43302RE: 140 x 85 x 30mm
Weight	PCR43302R: 60 grams	PCR43302RE: 145grams
Useable Transmitters	FOB433 series and PCK series	

Block Diagram



PentaFOB® Programming Instructions

Coding the PentaFOB® remotes and receivers can be done in 2 different ways.

1. Remote to Receiver
2. Remote to Remote

Remote to Receiver

1. Check that all switches are “OFF” on the receivers 12-way dip switch
2. Press and hold the program button on the receiver
3. Press the remote button for 2 seconds, receiver LED will flash and then turn Green
4. Release the button on the receiver and the remote
5. Press remote control button to test the receiver output

Remote to Remote (you should be near the receiver for this procedure)

**Only follow the following procedure if your receiver has a red marking as shown in the picture. If your receiver does not have this marking, follow the procedure which is in the orange text.*



1. Open the case of a remote control that is already programmed and press and release the program button on the back of the board (The receiver enters learning mode)
2. Press the button of the remote in step 1 which activates the receiver
3. Press the button on the new remote which needs to be programmed for 2 seconds
4. Press the program button again of the remote in step 1(The receiver exits learning mode)
5. Press the new remote control button to test the receiver output

For receiver's which do not have the red marking

1. **Open the case of a remote control that is already programmed and press and release the program button on the back of the board**
2. **Press the new remote control button for 2 seconds**
3. **Press the new remote control button again to test the receiver output**

Deleting Receivers Memory

Short the Code Reset pins on the receiver for 10 seconds. **This will delete all the remotes from the receiver's memory.**

PentaFOB® Programmer

This programmer allows you to add and delete certain remotes from the receiver memory. This is used when a remote control is lost or a tenant moves from the premises and the owner wants to prevent un-authorised access.

PentaFOB® Backup Chips

This chip is used to backup or restore the contents of a receiver. When there are 100's of remotes programmed to a receiver the installer normally backups the receiver memory in case the receiver is damaged.

PentaCODE® Programming Instructions

12-Way Dip Switch Coding

1. Set a random code on the receiver dip switch by flicking the dip switches "On" or "Off".
(DO NOT USE THE DEFAULT FACTORY SETTING FOR THE 12-WAY DIP SWITCH AS THIS IS A COMMON CODE)
2. Open the battery cover in the PentaCODE® remote.
3. Match the 12-way dip switch to the receivers 12-way dip switch.
4. Press button 1 on the remote and the receiver output should activate. This is indicated by the receiver LED.

To program the same PentaCODE® remote buttons 2, 3 or 4 to another receiver change dip switch 11 and 12 in the 2nd, 3rd and 4th receivers. For example:

	Receivers Dip Switch 11	Receiver Dip Switch 12
Receiver 1	Off	Off
Receiver 2	On	Off
Receiver 3	Off	On
Receiver 4	On	On

Dip switches 1 to 10 should all be the same in the remotes and the receivers.

Encrypted Coding - (All 12-Way Dip Switches must be "Off")

Coding the PentaCODE® remotes and receivers can be done in 3 different ways.

1. Receiver to a Remote
2. Remote to a Receiver
3. Remote to a Remote

➤ Receiver to a Remote

1. Press and hold the program button 1 on the receiver.
2. Press the remote button you want to program for 2 seconds, receiver LED will flash Green
3. Release the button on the receiver and the remote.
4. The LED on the PentaCODE® remote will flash to confirm the coding has been successful.

➤ Remote to a Receiver / Remote to a Remote

Set one of the remotes or receivers to broadcast its code. The broadcaster's code will be programmed to the other units.

- To broadcast the remotes code make sure all 12 dip switches are "off". Then press and hold button 1 and flick dip switch 12 "on" and then "off". This is confirmed by the LED's being on for 10 seconds. You can release the remotes button 1.

- To broadcast the receivers code make sure all 12 dip switches are "off" and then flick dip switch 12 "on" and then "off". This is confirmed by the green LED being on for 10 seconds.

While broadcasting the code press button 1 on a different remote or receiver for 1 second and then release the button. The LED will flash twice to confirm successful programming.

Broadcasting will be latched on for 10 seconds or stop if any dipswitch is turned on.

Deleting Receivers Memory

Short the CC pin on the receiver for 10 seconds. **This will delete all the remotes from the receiver's memory.**